

Thanks for choosing the Pro-Spec Easy Brake for your ride. Easy Brake for **HONDA TRANS ALP & RS 350** has been designed to offer a convenient braking experience for everyday riding while using riding boots or leisure footwear during short & long commutes. The Standing Assist provides convenient braking assistance when the riders choose to stand and ride their motorcycle.

Please follow the instructions carefully to ensure the desired benefit of the Easy Brake.

1. Insert the base lock plate into the triangular existing brake pedal.
2. Place the Easy Brake assembly and ensure matching the hole of the base lock.
3. Hand-tighten the 4X16 Allen bolt after ensuring to have the flat washer in place.  
*(please don't exert excess force while tightening)*



Sl.	DESCRIPTION	QTY.
1	Easy brake comfort base with standing assist	1
2	Base Lock	1
3	4x16 Allen head SS bolt (pre-fitted)	2
4	4x16 Allen head SS bolt with Flat washer	1
5	Allen key 3mm	1



*We advise the brake pedal to be always kept at a lower level with reference to the footrest to avoid unintentional engagement of the rear brake.*

*Note: Though the Easy Brake retrofits are designed for DIY installation it is recommended you have them installed by a technician if you face difficulty.*

1 Square 3rd Floor, 293/295/229,  
Hennur Main Road, Post, opp. IOCL Petrol Pump,  
Kalyan Nagar, Bengaluru,  
Karnataka 560043

