

MOUNTING INSTRUCTION – EASY BRAKE 640

PS IM 06

Thanks for choosing the Pro-Spec Easy Brake for your ride. Easy Brake for KTM 250/390 Adventure has been designed to offer a convenient braking experience for everyday riding while using riding boots or leisure footwear during short & long commutes. The Standing Assist provides convenient braking assistance when the riders choose to stand and ride.

Please follow the instructions carefully to ensure the desired benefit of the Easy Brake.

1. Place the comfort base on the on the brake lever such that the second hole of the comfort base aligns with the first hole on the brake lever. Tighten the comfort base to the lever with a 5x20 CSK screw (Line item 2) using a 3mm Allen key. As, shown in the picture below.
2. Place the shorter Allen head bolt under the comfort base to tighten one end of the standing assist using the 3mm Allen key.
3. Align the other end of the standing assist and comfort base to the last hole of the brake lever and insert the longer Allen head screw under the brake lever. Tighten the screw using a 3mm Allen key.



Sl.	DESCRIPTION	QTY.
1	Easy Brake comfort base with standing assist.	1
2	5x20 CSK bolt	1
3	4x16 SS Allen head bolt	1
4	4x35 SS Allen head bolt	1
5	Allen key 3mm	1



We advise the brake pedal to be always kept at a lower level with reference to the foot rest to avoid unintentional engagement of rear brake.

Note: Though the Easy Brake retrofits are designed for DIY installation it is recommended you have them installed by a technician if you face difficulty.

I Square 3rd Floor,293/295/229,
Hennur Main Road, Post, opp. IOCL Petrol Pump,
Kalyan Nagar, Bengaluru,
Karnataka 560043

